# () STREAMLINE INSTRUCTION MANUAL

### **ULTRALITE**

#### **Codes:**

**UL-POLE-01900** 

**UL-POLE-03500** 

**UL-POLE-05150** 

UL-POLE-06750

UL-POLE-08440

UL-POLE-10090

UL-POLE-11720

UL-POLE-13370

UL-POLE-15000

UL-POLE-16700

UL-POLE-19300

**UL-POLE-22500** 

#### **Kit Includes:**

1x ULTRALITE™ Window Cleaning Pole

English

INSTR-ULPOLF

- V SEAULE OF THE STATE OF THE



The STREAMLINE® ULTRALITE™ is probably the lightest window cleaning pole on the market today, thus, taking the effort out of window cleaning. Care needs to be taken when assembling, operating and disassembling the pole.

Push the brush/swan neck attachment onto the end of the thinnest section. Connect the yellow LITE-5® pole tubing to the white Y-piece which supplies water to the brush jets. Continue to add extra sections to the bottom end of the pole, clipping the LITE-5® tubing to the rubber receptacles at the end of each section. Connect the end hose fitting into the water supply hose and commence cleaning.

DO NOT USE EXCESSIVE FORCE WHEN JOINING THE SECTIONS, as this may cause the sections to split, and make the disassembly of the sections difficult. A thin film of lubricant, such as Vaseline, can be used to lubricate each male taper section, so as to facilitate ease of disassembly. The pole is delicate and care should be taken when using it.

- DO NOT allow the pole to fall or blow over in the wind.
- DO NOT use excessive force when using the pole, either by squeezing or overreaching.
- DO NOT attempt to close windows or top lights by using the pole.
- DO NOT knock the pole against window reveals or sharp brickwork or render edges.

Once the job is complete, remove the sections by reversing the above procedure. Care should be taken to avoid dropping the sections onto their edges as this is likely to cause damage and invalidate your warranty. Store the pole sections inside each other (except if you have purchased section 7 which must be stored separately) in a safe place, preferably in the plastic tube in which you received them, so as to eliminate any possibilities of damage.

# **STREAMLINE® Warranty**

The warranty on all Machines and Equipment is for 1 year (12-months) from RECORDED DATE OF PURCHASE.

THIS WARRANTY EXCLUDES NORMAL MAINTENANCE ITEMS, including but not limited to HOSES, FILTERS, O-RINGS, DIAPHRAGMS, VALVES, GASKETS, CARBON BRUSHES and damage to motors and other components as a result of failure to replace normal maintenance items. THIS LIST IS NOT EXHAUSTIVE.

If **STREAMLINE**\* receives notice of such defects during the warranty period, **STREAMLINE**\* will either, at its opinion, repair or replace components which prove to be defective.

Replacement parts will only be supplied under warranty, upon the inspection and approval of the defective parts by **STREAMLINE**\*.

Should it be necessary to supply replacement parts before the opportunity to inspect, these will be charged at current prices and credit will only be issued upon subsequent inspection and warranty approval by **STREAMLINE**\*.

The customer is responsible for the cost of return of the defective part. If warranty is approved, **STREAMLINE**\* will pay for the cost of the repaired or replacement part.

This warranty excludes the following conditions and circumstances which are at the discretion of **STREAMLINE**\*:

Wear and tear, misuse, abuse improper maintenance, frost damage, the use of chemicals other than those supplied or approved by **STREAMLINE**\*, improper installation or repair, unauthorised modification, incidental or consequential costs, loss or damage, service, labour or third party charges, the cost of returning defective parts to **STREAMLINE**\*.

This warranty constitutes the exclusive remedy of any purchaser of a **STREAMLINE**\* unit and is in lieu of all other warranties, express or implied, including without limitation any implied warranty of merchantability or fitness for use, to the fullest extent permitted by law. In no event shall any implied warranty of merchantability or fitness for use exceed the term of the applicable warranty stated above and **STREAMLINE**\* shall have no other obligation or liability.

### Important

Unfortunately these rights cannot be transferred to a third party.









3



**Notes** 

5

# Why STREAMLINE®?

## Flexibility

- **STREAMLINE**® systems can be built according to customers' exact requirements
- For non-standard systems, the user's needs or specifications are listened to and turned into reality.

#### Quality

- Whilst price is important, quality is remembered long after price is forgotten
- We insist on sourcing brand name products from around the world, only of a reputable quality, and bring them together under the STREAMLINE\* name
- All STREAMLINE® products carry a full one year's warranty, according to the manufacturers' standard terms and conditions of sale.

#### Service

- We have an in-house technical helpline able to answer most of your questions relating to the capabilities and functionalities of all STREAMLINE\* products
- If we get it wrong, we will put it right. If you are sent a wrong item, we will immediately
  attend to sending you the correct item and arrange a collection of the wrong item without
  any quibbles
- **STREAMLINE\*** is backed by a comprehensive range with massive stocks providing you with a 'one stop shop' for all your requirements.





CHECKED AND TESTED BY QUALITY CONTROL

•••••	 	 	
•••••	 	 	
•••••	 	 	
•••••	 	 	



Heathfield Industrial Estate,

Telephone: +44 (0) 1626 830 830

INSTR-ULPOLE